

Disc

The disc inserted in the front cover contains the user manual of the models **DuCoNite®** 10, **DuCoNite®** 15 and **DuCoNite®** 20. The user manual is available in the following languages:

Český	Español	Nederlands	Русский
Dansk	Français	Norsk	Svenska
Deutsch	Italiano	Polski	Suomi
English (UK)	Magyar	Português	
English (US)			

The disc also contains quick-reference instructions for the replacement of the pump hose. This replacement instruction is only for users that are familiar with the replacement procedures in the user manual.

How to use the disc

- 1 Put the disc in the disc drive.
- 2 Close the disc drive.
The disc will start automatically.
- 3 Wait until the various language versions appear on screen.
- 4 Select the required language (click 1x with the left mouse button).
The PDF reader program will automatically start and the required user manual appears on screen.

Shortcuts

In the left margin you will find the various chapters and paragraphs. These can be accessed directly by clicking on the required chapter or paragraph.

In the text you will find hyperlinks to chapters or paragraphs. These hyperlinks are linked with the required chapters or paragraphs. By clicking a shortcut the required chapter or paragraph appears on screen.

System requirements

The program on the disc requires a PC with the following minimum system requirements:


- Disc drive

The following software must be installed on the PC:

- PDF reader program
- An Internet browser

Hose pump series DuCoNite[®] 10, DuCoNite[®] 15 and DuCoNite[®] 20

Manual



© 2013 Watson-Marlow Bredel B.V.

All rights reserved.

The information provided herein may not be reproduced and/or published in any form, by print, photoprint, microfilm or any other means whatsoever (electronically or mechanically) without the prior written authorisation of Watson-Marlow Bredel B.V.

The information provided can be changed without prior notification. Watson-Marlow Bredel B.V. or one of its representatives cannot be held liable for possible damage resulting from use of this manual. This is an extensive limitation of the liability which applies to all damage, inclusive of (without limitation) compensating, direct, indirect or consequential damage, loss of data, income or profit, loss or damage to possessions and claims of third parties.

Watson-Marlow Bredel B.V. provides the information in this manual "as is" and does not take any responsibility and does not give any guarantee on this manual or its content. Watson-Marlow Bredel B.V. rejects all responsibilities and guarantees. Furthermore, Watson-Marlow Bredel B.V. does not take responsibility for and does not guarantee that the information in this manual is accurate, complete or up to date.

Names, trade names, brands, etc. used by Watson-Marlow Bredel B.V. may not, as per the legislation concerning the protection of trade names, be considered as available.

CONTENTS**1 GENERAL**

1.1	<i>How to use this manual</i>	8
1.2	<i>Original instructions</i>	8
1.3	<i>Other supplied documentation</i>	8
1.4	<i>Service and support</i>	8
1.5	<i>Environment and disposal of waste</i>	9

2 SAFETY

2.1	<i>Symbols</i>	10
2.2	<i>Intended use</i>	10
2.3	<i>Use in potentially explosive atmospheres</i>	11
2.4	<i>Use in corrosive atmosphere</i>	11
2.5	<i>Responsibility</i>	11
2.6	<i>Qualification of the user</i>	12
2.7	<i>Regulations and instructions</i>	12

3 WARRANTY CONDITIONS**4 DESCRIPTION**

4.1	<i>Identification of the product</i>	14
4.1.1	<i>Identification of the product</i>	14
4.1.2	<i>Identification of the pump</i>	14
4.1.3	<i>Identification of the rotor</i>	14
4.1.4	<i>Identification of the gearbox</i>	15
4.1.5	<i>Identification of the electric motor</i>	15
4.1.6	<i>Identification of the frequency controller</i>	16
4.1.7	<i>Identification of the pump hose</i>	16
4.2	<i>Construction of the pump</i>	17
4.3	<i>Operation of the pump</i>	18
4.4	<i>Pump hose</i>	19
4.4.1	<i>General</i>	19
4.4.2	<i>Hose compression force adjustment</i>	20
4.4.3	<i>Lubrication and cooling</i>	20
4.5	<i>Gearbox</i>	20
4.6	<i>Electric motor</i>	20
4.7	<i>Frequency controller</i>	21
4.8	<i>Available options</i>	21

5	INSTALLATION	
5.1	<i>Unpacking</i>	22
5.2	<i>Inspection</i>	22
5.3	<i>Installation conditions</i>	22
5.3.1	Ambient conditions	22
5.3.2	Set-up	22
5.3.3	Pipework	23
5.3.4	Frequency controller	24
5.3.5	High Level Control (HLC)	25
5.4	<i>Lifting and moving the pump</i>	26
5.5	<i>Placing the pump</i>	26
6	COMMISSIONING	
6.1	<i>Preparations</i>	27
6.2	<i>Commissioning</i>	28
7	MAINTENANCE	
7.1	<i>General</i>	29
7.2	<i>Maintenance and periodic inspections</i>	29
7.3	<i>Additional maintenance in potentially explosive environments</i>	31
7.4	<i>Cleaning the pump hose</i>	31
7.5	<i>Changing lubricant</i>	32
7.6	<i>Replacing pump hose</i>	33
7.6.1	Removing pump hose	33
7.6.2	Cleaning the pump head	34
7.6.3	Fitting the pump hose	35
7.7	<i>Exchanging replacement parts</i>	37
7.7.1	Replacing rotor, bearings and seal ring	37
7.8	<i>Options</i>	41
7.8.1	Revolution counter	41
7.8.2	Drain connection	42
8	STORAGE	
8.1	<i>Hose pump</i>	43
8.2	<i>Pump hose</i>	43
9	TROUBLESHOOTING	

10 SPECIFICATIONS

10.1	<i>Pump head</i>	49
10.1.1	Performance	49
10.1.2	Materials	50
10.1.3	Surface treatment	51
10.1.4	Chemical resistance chart DuCoNite® coating	51
10.1.5	Lubricant table pump	52
10.1.6	Weights	52
10.1.7	Torque figures	53
10.2	<i>Gearbox</i>	54
10.3	<i>Electric motor</i>	54
10.4	<i>Variable Frequency Drive (VFD) (optional)</i>	55
10.5	<i>Parts list</i>	56
10.5.1	Overview	56
10.5.2	Cover assembly	57
10.5.3	Pump head assembly	59
10.5.4	Support assembly	60
10.5.5	Barbed nipple assembly (PTFE/PDVF)	61
10.5.6	Barbed or threaded nipple assembly (stainless steel)	62
10.5.7	Flange assembly (1)	63
10.5.8	Flange assembly (2)	64
10.5.9	Revolution counter assembly	65
10.5.10	Lubricants	65

EC DECLARATION OF CONFORMITY FOR MACHINERY**SAFETY FORM**

1 GENERAL

1.1 How to use this manual

This manual is intended as a reference book by means of which qualified users are able to install, commission and maintain the hose pumps mentioned on the front cover.

1.2 Original instructions

The original instructions for this manual have been written in English. Other language versions of this manual are a translation of the original instructions.

1.3 Other supplied documentation

Documentation of components such as the gearbox, the motor and the frequency controller is not included in this manual. However, if additional documentation is supplied, you must follow the instructions in this additional documentation.

1.4 Service and support

For information with respect to specific adjustments, installation, maintenance or repair jobs which fall beyond the scope of this manual, contact your Bredel representative. Make sure you have the following data at hand:

- Serial number hose pump
- Article number pump hose
- Article number gearbox
- Article number electric motor
- Article number frequency controller

You will find these data on the identification plates or stickers of the pumphead, the pump hose, the gearbox and the electric motor. Refer to § 4.1.1.

1.5 Environment and disposal of waste

**CAUTION**

Always observe the local rules and regulations with respect to processing (non reusable) parts of the hose pump.

Enquire within your local government about the possibilities for reuse or environment-friendly processing of packaging materials, (contaminated) lubricant and oil.

2 SAFETY

2.1 Symbols

In this manual the following symbols are used:

	WARNING Procedures which, if not carried out with the necessary care, may result in serious damage to the hose pump or in serious bodily harm.
--	--

	CAUTION Procedures which, if not carried out with the necessary care, may result in serious damage to the hose pump, the surrounding area or the environment.
--	---

	Remarks, suggestions and advice.
---	----------------------------------

	WARNING Procedures, remarks, suggestions or advice which refer to use in potentially explosive atmospheres in accordance with the ATEX Directive 94/9/EC.
--	---

2.2 Intended use

The hose pump is exclusively designed for pumping suitable products. Every other or further use is not in conformance with the intended use.

The "Intended use" as laid down in EN 292-1 is "... the use for which the technical product is intended in accordance with the specifications of the manufacturer, inclusive of his indications in the sales brochure". In case of doubt it is the use which appears to be its intended use judging from the construction, execution

and function of the product. Observing the instructions in the user's documentation also belongs to intended use.

Only use the pump in conformance with the intended use described above. The manufacturer cannot be held responsible for damage or harm resulting from use that is not in conformance with the intended use. If you want to change the application of your hose pump, contact your Bredel representative first.

2.3 Use in potentially explosive atmospheres

The pump mentioned in this manual can be configured for use in a potentially explosive atmosphere. For use in Europe, such a pump complies with the European Directive 94/9/EC (ATEX).

The pumps belong to:

- Group II Appliances, category 2 GD bck T5



Use in potentially explosive atmospheres requires special configuration of the pump unit. Contact your Watson-Marlow Bredel representative for use in explosive atmospheres.

2.4 Use in corrosive atmosphere

The **DuCoNite**[®] pump head is coated (both in- and externally) with a corrosion and wear resistant coating. This coating withstands highly oxidising and reducing media. Refer to § 10.1.4 for a specification.

2.5 Responsibility

The manufacturer does not accept any responsibility for damage or harm caused by not (strictly) observing the safety regulations and instructions in this manual and the also supplied documentation, or by negligence during installation, use, maintenance and repair of the

hose pumps mentioned on the front cover. Depending on the specific working conditions or accessories used, additional safety instructions can be required. Immediately contact your Bredel representative, if you noticed a potential danger while using your hose pump.

**WARNING**

The user of the hose pump is always fully responsible for observing the local valid safety regulations and directives. Observe these safety regulations and directives when using the hose pump.

2.6 Qualification of the user

The installation, use and maintenance of the hose pump should only be performed by well-trained and qualified users. Temporary staff and persons in training may use the hose pump only under the supervision and responsibility of trained and qualified users.

2.7 Regulations and instructions

- Everyone who works with the hose pump must be aware of the contents of this manual and observe the instructions with great care.
- Never change the order of the actions to be carried out.
- Always store the manual near the hose pump.

3 WARRANTY CONDITIONS

The manufacturer offers a two-year warranty on all parts of the hose pump. This means that all parts will be repaired or replaced free of charge, with the exception of consumables, such as pump hoses, hose clamps, ball bearings, wear rings, and seals, or parts which have been misused or have been intentionally damaged.

If parts are used that are not Watson-Marlow Bredel B.V. (hereafter called Bredel) parts, every warranty becomes void.

Damaged parts which are covered by the applicable warranty conditions can be returned to the manufacturer. The parts must be accompanied by a fully filled in and signed safety form, as present in the back of this manual. The safety form must be applied to the outside of the shipping carton. Parts which have been contaminated or which have been corroded by chemicals or other substances which can pose a health risk, must be cleaned before they are returned to the manufacturer. Furthermore, it should be indicated on the safety form which specific cleaning procedure has been followed, and it should be indicated that the equipment has been decontaminated. The safety form is required at all items, even if the parts have not been used.

Warranties purporting to be on behalf of Bredel, made by any person, including representatives of Bredel, its subsidiaries, or its distributors, which do not accord with the terms of this warranty shall not be binding upon Bredel unless expressly approved in writing by a Director or Manager of Bredel.


4 DESCRIPTION

4.1 Identification of the product

4.1.1 Identification of the product

The hose pump can be identified based on the identification plates or stickers on:

- A:** Pump head
- B:** Gearbox
- C:** Electric motor
- D:** Pump hose
- E:** Frequency controller



4.1.2 Identification of the pump

The identification plate on the pump head contains the following data:

- A:** Pump type
- B:** Serial number and rotor identification letter¹
- C:** Year of manufacture



4.1.3 Identification of the rotor

The rotor identification letter identifies which type of rotor is mounted to the pump. The table below shows the rotor identification letter and the article number of the mounted rotor. Also refer to [10.5.3](#).

Letter	DuCoNite® 10	DuCoNite® 15-20
blank	no rotor	no rotor
A	210103LN	215103LN


¹ For information on the rotor identification letter, refer to [4.1.3](#).

Letter	DuCoNite® 10	DuCoNite® 15-20
B	210103HN	215103HN
C	-	220103LN
D	-	220103HN

4.1.4 Identification of the gearbox

The identification plate on the gearbox contains the following data:


- A:** Article number
- B:** Serial number
- C:** Type number
- D:** Reduction ratio
- E:** Number of revolutions per minute



4.1.5 Identification of the electric motor

The identification plate on the electric motor contains the following data:


- A:** Type number
- B:** Serial number
- C:** Article number
- D:** Mains
- E:** Frequency
- F:** Speed
- G:** Power
- H:** Power factor
- I:** Current



4.1.6 Identification of the frequency controller

The identification of the Bredel Variable Frequency Drive (VFD) can be found inside the VFD. Remove the cover by loosening the two screws. The identification sticker contains the following data:


- A:** Article number
B: Serial number




4.1.7 Identification of the pump hose

The identification sticker on the pump hose contains the following data:

- A:** Pump type
B: Reorder number
C: Internal diameter
D: Type of material of inner liner
E: Remarks, if applicable
F: Maximum permissible working pressure
G: Production code



4.2 Construction of the pump

- A:** Cover
- B:** Rotor
- C:** Pump hose
- D:** Pump housing
- E:** Support
- F:** Gearbox
- G:** Electric motor
- H:** Frequency controller




4.3 Operation of the pump

The heart of the pump head consists of a specially constructed pump hose (A) which lies contorted against the inside of the pump housing (B). Both ends of the hose are connected to the suction and discharge lines. A bearing-mounted rotor (D) with two facing pressing shoes (E) is in the centre of the pump head.

In phase 1 the lower pressing shoe compresses the pump hose by the rotational movement of the rotor, forcing the fluid through the hose. As soon as the pressing shoe has passed, the hose recovers to its original shape due to the mechanical properties of the material.

In phase 2 the product is drawn into the hose by the (continuous) turning motion of the rotor.


In phase 3, the second pressing shoe will subsequently compress the pump hose. Due to the continuous rotating movement of the rotor not only new product is sucked in, but also the already present product is pressed out by the pressing shoe. When the first pressing shoe runs from the pump hose, the second pressing shoe has already closed the pump hose and the product is prevented from flowing back. This method of liquid displacement is also known as the "positive displacement principle".



4.4 Pump hose

4.4.1 General

- A:** Outer extruded layer made of natural rubber
- B:** Two nylon reinforcement layers
- C:** Inner extruded liner



The pump hose liner material should be chemically resistant with the product to be pumped. Dependent on the specific requirements of your application a corresponding pump hose must be selected. For each pump model various hose types are available.

The material of the inner liner of the pump hose determines the hose type. Each hose type is marked by a unique colour code.

Hose type	Material	Colour code
NR	Natural rubber	Purple
NBR	Nitrile rubber	Yellow
EPDM	EPDM	Red
CSM	CSM	Blue



Consult your Bredel representative for more detailed information about the chemical and temperature resistance of pump hoses.

The Bredel pump hoses have been carefully machined, therefore there are minimum tolerances in wall thickness. It is very important to guarantee the correct compression of the pump hose, because:

- When the compression is too high, it creates a too high load of the pump and pump hose, which may result in a reduction of the life of the pump hose and bearings.

- When the compression is too low, this will result in loss of capacity and backflow. Backflow results in a reduction of the life of the pump hose.

4.4.2 Hose compression force adjustment

The compression force of the pump hose can be adjusted by installing a rotor with a different dimension between the tips of the integral pressing shoes. The rotor is chosen to achieve an optimal life of the pump hose for the intended use of the hose pump. If you want to change the application of your hose pump, contact your Bredel representative.

4.4.3 Lubrication and cooling

The pumphead, in which the rotor and pump hose can be found, is filled with Bredel Genuine Hose Lubricant. This lubricant lubricates the movement between the hose and the pressing shoes and dissipates the generated heat via the pump housing and the cover.

The lubricant is food grade. See § 10.1.5 for the required quantity and NSF registration.

	Consult your Bredel representative for lubrication recommendations when operating the hose pump below 2 rpm.
---	--

4.5 Gearbox

The hose pump types described in this manual use helical gearbox units. The gearboxes are fitted with a flange connection. Refer to § 10.2 for specifications.

4.6 Electric motor

If the electric motor has been standard supplied by the manufacturer, it is a standardized squirrel-cage motor. Refer to § 10.3 for specifications.

4.7 Frequency controller

Refer to the also supplied documentation of the supplier and § 10.4.

4.8 Available options

The next options are available for the hose pump:

- Revolution counter
- Low or medium pressure rotor
- Drain connection
- Frequency controller
- Special configuration for use in explosive atmospheres

**WARNING**

If the pump is to be used in potentially explosive atmospheres, contact your Bredel representative.

5 INSTALLATION

5.1 Unpacking

When unpacking carefully follow the instructions as given on the packaging or on the hose pump.

5.2 Inspection

Check that your delivery is correct and check it for any transport damage. Refer to § 4.1.1. Report any damage immediately to your Bredel representative.

5.3 Installation conditions

5.3.1 Ambient conditions

Make sure that the hose pump is in an area where the ambient temperature during operation is not lower than -20 °C and not higher than +45 °C.

5.3.2 Set-up

- The pump materials and protective layers are suitable for indoor set-up and a protected outdoor set-up. Under certain conditions the pump is suitable for limited outdoor set-up or a salty or aggressive atmosphere. Consult your Bredel representative for more information.
- Make sure that the floor surface is horizontal and has a maximum slope of 10 mm per metre.
- Make sure that there is sufficient room around the pump to carry out the necessary maintenance activities.
- Make sure that the room is sufficiently ventilated, so that the heat developed by the pump and drive can be discharged. Keep some distance between the ventilation cover of the electric motor and wall to enable the supply of necessary cooling air.

5.3.3 Pipework

When determining and connecting suction and discharge lines consider the following points:


- The bore size of the suction and discharge lines must be larger than the bore size of the pump hose. For more information consult your Bredel representative.
- Limit the presence of sharp bends in the discharge line. Make sure that the radius of the bent discharge line is as large as possible (preferably 5S). It is recommended to use Y-connections instead of T-connections.
- It is recommended to use a minimum of three quarters (3/4) of the hose length as flexible hose in the suction or discharge line. This avoids the need to remove the connection lines when changing a pump hose.
- Keep the delivery and suction lines as short and direct as possible.
- Select the correct mounting material for flexible hoses and make sure that the installation is suited for the design pressure of the system.
- Prevent any possibilities of exceeding the maximum working pressure of the hose pump. Refer to § 10.1.1. If necessary fit a pressure relief valve.

**CAUTION**

Consider the maximum permissible working pressure on the discharge side. Exceeding the maximum working pressure may lead to serious damage to the pump.

- Make sure that the maximum forces on the flanges are not exceeded. The permissible loads are given in the following table.

Maximum permissible loads [N] on the pump connections			
Force	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
F1	600	600	600
F2	300	300	300
F3	120	120	120



	<p>CAUTION</p> <p>In case of hose failure, the product or a mixture of product and lubricant can leak by the breather cap. If this risk is not acceptable, drain piping can be connected, refer to § 7.8.2.</p>
--	--

	<p>WARNING</p> <p>The maximum pump temperature is 60 °C. Above this temperature the corrosion speed can rise excessively, depending on the product.</p>
--	--

5.3.4 Frequency controller

	<p>WARNING</p> <p>A frequency controller that is fitted <i>without the manual control</i> can start automatically when power is applied.</p>
--	---

If the hose pump is fitted with a frequency controller, consider the following points:


- Take precautions so the motor does not re-start automatically after an unscheduled stop. In the event of a power or mechanical failure, the frequency controller controls the motor to stop. When the cause of the failure is removed,

the motor can restart automatically. The automatic restart can be dangerous in certain pump installations.

- All control cables outside the enclosure must be shielded and have a cross sectional area between 0.22 and 1 mm². The shielding must be connected to earth at both ends.


5.3.5 High Level Control (HLC)

To sense the lubricant level inside the pump housing the pump is provisioned with a floater. The HLC floater (A) is positioned above the normal lubricant level of the pump. When a hose fails, the product will be pressed into the pump casing and causes a level rise of the lubricant. The HLC shall detect this rise of lubricant. After hose failure, the floater needs to be cleaned.




Connection of floaters:

The floater has to be connected to the auxiliary power circuit via the 1 meter long PVC cable (2 x 0.24 mm²).



Specifications	
Scope:	For use in non-explosive environments
Voltage:	Max. 230 V AC/DC
Current:	Max. 1 A
Power:	Max. 50 VA



	<p>Where the floater is constructed to stop the equipment, operating has to be arranged so that the stop function locks-out, preventing the equipment from being re-started without re-setting. Check if the floater is mounted with the NC sign at the top.</p>
--	--



5.4 Lifting and moving the pump

For lifting and moving the hose pump, the pump support has a lifting eye (A).

The complete hose pump, i.e. pump head, gearbox and electric motor, must be lifted using the lifting eye plus additional support using suitably rated straps or slings (A). For the weights, refer to § 10.1.6.



WARNING

If the pump is to be lifted ensure that all standard lifting practises are adhered to and carried out by qualified personnel only.

5.5 Placing the pump

Position the pump on a horizontal surface. Use suitable anchor bolts to attach the pump to the floor surface.

6 COMMISSIONING

6.1 Preparations

**WARNING**

A frequency controller that is fitted *without manual control* can start the pump automatically when power is applied.

**WARNING**

Disconnect and lock the power supply to the pump drive before any work is carried out.

In case the motor is fitted with a frequency controller and has a single-phase power supply, wait two minutes to make sure that the capacitors have discharged.

1. Connect the electric motor and, if present, the frequency controller in conformance with the locally applicable rules and regulations. Refer to § 5.3.4. Have the electrical installation work carried out by qualified personnel.
2. Check that the lubricant level is above the minimum level line in the inspection window. If necessary refill with Bredel Genuine Hose Lubricant via the breather plug. See also § 7.5.

6.2 Commissioning

1. Connect the pipework.
2. Make sure that there are no obstructions such as closed valves.
3. Switch on the hose pump.
4. Check the rotation of the rotor.
5. Check the capacity of the hose pump. If the capacity differs from your specification, follow the instructions in chapter 9 or consult your Bredel representative.
6. Check the capacity range of the frequency controller. In case of any deviations consult the documentation of the supplier.
7. Check the hose pump in accordance with points 2 to 4 of the maintenance table from § 7.2.

7 MAINTENANCE

7.1 General

**WARNING**

Disconnect and lock the power supply to the pump drive before any work is carried out.

In case the motor is fitted with a frequency controller and has a single-phase power supply, wait two minutes to make sure that the capacitors have discharged.

**WARNING**

Only use original Bredel parts when maintaining the hose pump. Bredel cannot guarantee correct operation and any consequential damage that occurs from the use of non-original Bredel components.

See also chapters [2](#) and [3](#).

7.2 Maintenance and periodic inspections

The following maintenance scheme shows the maintenance and periodic inspection that need to be carried out on the hose pump to guarantee optimal safety, operation and life of the pump.

Point	Action	To be carried out	Remark
1	Check the lubricant level.	Before startup of the pump and on a scheduled interval during operation.	Make sure that the lubricant level is above the minimum level line in the inspection window. If necessary refill the lubricant. See also § 7.5.
2	Check the pump head for any leakage of lubricant around the cover, the brackets and the rear of the pump head.	Before startup of the pump and on a scheduled interval during operation.	See § 9.
3	Check the gearbox for any leakage.	Before startup of the pump and on a scheduled interval during operation.	In case of leakage consult your Bredel representative.
4	Check the pump for deviating temperature or strange noises.	On a scheduled interval during operation.	See § 9.
5	Check the rotor with integral pressing shoes for excessive wear.	When replacing the pump hose.	See § 7.6.
6	Internal cleaning of the pump hose.	Cleaning of the system or product change.	See § 7.4.
7	Replace the pump hose.	Preventive, this means after 75% of the hose life of the first hose.	See § 7.6.
8	Change lubricant.	After every 2 nd hose change or after 5,000 service hours, whichever comes first or after hose rupture.	See § 7.5
9	Replace the seal ring.	If necessary.	See § 7.7.1.
10	Check the wear ring.	When the pump seal is replaced, check the running surface of the wear ring for excessive wear.	For replacement, contact your Bredel representative.

Point	Action	To be carried out	Remark
11	Replace the rotor with integral pressing shoes.	Wear on the running surface of the pump hose and/or seal ring.	
12	Replace the bearings.	If necessary.	See § 7.7.1.

7.3 Additional maintenance in potentially explosive environments

The following maintenance scheme shows the additional maintenance and periodic inspections that need to be carried out on the hose pump to guarantee an optimal safety, operation and life of the pump in a potentially explosive environment.


Point	Action	To be carried out	Remark
1	Replacing bearings.	According to ATEX regulations after 40,000 hrs. service or when damage is suspected.	See § 7.7.1.
2	Cleaning the hose pump.	In potentially explosive (dust) atmospheres, the dust must be removed regularly.	

7.4 Cleaning the pump hose


The inside of the pump hose can be easily cleaned by rinsing the pump with clean water. If a cleaning fluid is added to the water, check if the hose liner material is resistant to it. Also check if the pump hose can resist the cleaning temperature. Special cleaning balls are also available. Contact your Bredel representative for more details.

7.5 Changing lubricant


1. Place a tray (A) under the drain plug in the cover of the pump. Remove the drain plug (B). Catch the lubricant from the pump housing in the tray.



2. Position the drain plug (A) and tighten it firmly. For DuCoNite® 15 and DuCoNite® 20, remove the breather plug (B) before filling the lubricant. The DuCoNite® 10 can be filled without de-aerating.




3. The pump housing can be filled with lubricant via the breather (A) on the cover. For this purpose remove the breather cap (B) and position a funnel (C) in the breather. Pour the lubricant in the pump housing via the funnel.



4. Keep on pouring until the lubricant level has risen above the level line in the inspection window.
For DuCoNite® 15 and DuCoNite® 20, mount the breather plug (A) into the inspection window.





For the required quantity of lubricant, refer to § 10.1.5.





7.6 Replacing pump hose

7.6.1 Removing pump hose

1. Isolate the pump from the electrical supply.
2. Close any shut-off valves in both the suction and discharge line to minimize product loss.
3. Place a tray (A) under the drain plug in the bottom of the pump head. The tray must be large enough to contain the lubricant, possibly contaminated with product fluid, from the pump head. Remove the drain plug (B). Catch the lubricant from the pump housing in the tray. Check that the breather mounted on the cover is not obscured. Position the drain plug and tighten it firmly.
4. Disconnect the suction and discharge lines.
5. Loosen hose clamp (A) of both the inlet and outlet ports by loosening bolt (B).




6. Loosen the retaining bolts (A) of the bracket (B) and remove the bolts.
7. Pull the bracket and hose clamp from the hose. Then pull off the rubber bush (C).
Do steps 6 to 7 both for the inlet and outlet ports.
8. Switch on the electrical supply.
9. Power out the hose (A) from the pump chamber by jogging the drive motor.



	<p>WARNING</p> <p>During jogging the drive:</p> <ul style="list-style-type: none"> - Do not stand in front of the pump ports. - Do not try to guide the hose by hand.
--	--

7.6.2 Cleaning the pump head

1. Isolate the pump from the electrical supply.
2. Remove the cover (B) by loosening the retaining bolts (A).
3. Check the gasket (C) and replace it if necessary.
4. Rinse the pump head with clean water and remove all residues. Make sure that no rinsing water remains in the pump head.



5. Check the rotor for wear or damage and replace the rotor if necessary. Also see the maintenance scheme in § 7.2.


**CAUTION**

When the rotor is worn the compression force of the hose decreases. If the compression force is too low, this results in a loss of capacity by the backflow of the liquid to be pumped.
Backflow results in a reduction of the life of the pump hose.

6. Replace the cover and fasten the retaining bolts with the correct torque. Refer to § 10.1.7.
7. Switch on the electrical supply to the pump.

7.6.3 Fitting the pump hose


1. Clean the (new) pump hose on the outside and fully lubricate it with Bredel Genuine Hose Lubricant.
2. Fit the pump hose (A) via one of the ports.
3. Let the motor run to let the rotor pull the hose in the pump housing. Stop the motor when the hose sticks out equally from both sides of the pump housing.

**WARNING**


During jogging the drive:

- Do not stand in front of the pump ports.
- Do not try to guide the hose by hand.


4. Check that the rubber bushes (A) are not deformed or damaged and replace them if necessary.
5. Check that the hose clamps (B) are not damaged and replace them if necessary.



6. First fit the inlet port.
Slide the rubber bush (D) over the hose.
Push the bracket (A) and the hose clamp (B) over the hose together. Align the holes in the bracket with the ones at the front of the port. Position the two retaining bolts (C) and tighten them. Make sure the bolts are tightened with the correct torque. Refer to § 10.1.7.




7. Turn the rotor in such a way that the hose (A) is pressed firmly against the bracket (B).



8. Tighten the bolt (A) of the hose clamp (B). Make sure the bolt is tightened with the correct torque. Refer to § 10.1.7.

9. Now fit the other port. For this port proceed in the same way as described above for the inlet port.





10. Fill the pump housing with Bredel Genuine Hose Lubricant. Refer to § 7.5.
11. Connect the suction and discharge lines.


7.7 Exchanging replacement parts

7.7.1 Replacing rotor, bearings and seal ring

1. Remove the pump hose. Refer to § 7.6.1.
2. Isolate the pump from the electrical supply.
3. Remove the cover (B) by loosening the retaining bolts (A).
4. Check the gasket (C) and replace it if necessary.
5. Put the hose pump on blocks. Make sure the space between the blocks is wide enough for the rotor to fall.



6. Remove the nuts (B), washers (C) and the pump drive (A).





7. Put a plastic or wooden drive pin (A) on the rotor.


8. Hit the drive pin firmly with a hammer to remove the rotor.

9. Put the hose pump upright on the support.


10. Dismount the circlip (A) with the correct tool.




11. Dismount the bearings (A) with the correct tool, the spacer ring (B) and the retaining ring (C).




12. Remove the seal ring (A). Clean and degrease the bore.




13. Fit a new seal ring (A) using good engineering practises. The seal ring must be fitted in the correct orientation (B). Make sure that the open side points to the pump cover.




14. Check that the hub is clean and free of grease. Fit the bearings and the rings. The bearings are placed on the hub with a slight interference fit. Use a pressing tool to press the bearings on the hub.



15. Mount the circlip (A).




16. Fit the rotor (A). The rotor is placed on the bearings with a loose fit. Press the rotor on the hub until it clicks on the retaining ring.



17. Put the hose pump on two blocks.

18. Grease the coupling teeth (A) with graphite-loaded grease. Ensure the mating faces of the drive end pump are clean, dry and free from lubricant.




19. Fit the pump drive (B) with the nuts (C) and washers (D). Tighten to the specified torque settings. Refer to § 10.1.7.

20. Put the hose pump upright on the support.

21. Check the position of the rotor. If necessary press the rotor on the hub until it clicks on the retaining ring.

22. Refit the cover (B). Make sure that the 4 bolts (A) are refitted and that they are tightened in the correct order, diagonally opposite each other. Refer to § 10.1.7.




23. Switch on the electrical supply to the pump.

24. Fit the (new) pump hose. Refer to § 7.6.3.

7.8 Options

7.8.1 Revolution counter


For feedback of the pump revolutions to an "intelligent" system, the pump can be provided with an inductive sensor (A). This sensor is mounted between the two ports.



Connection of the revolution counter:


The speed sensor can be connected via the 2 meter long PVC cable (3 x 0.34 mm²).

Specifications	
Scope:	For use in non-explosive environments
Voltage:	10...30 VDC
Current:	Max. 200 mA



Adjustment sensor:

The sensor (A) must be adjusted at an offset of 0.75-1.25 mm to the rotor (B).




7.8.2 Drain connection

Drain piping can be connected with an optional part (A) fitted at the breather. This is a 1" NPT threaded connection.

**CAUTION**

The drain piping must be connected to an open reservoir, to prevent pressure built up inside the pump housing.



8 STORAGE

8.1 Hose pump

- Store the hose pump or pump parts in a dry area. Make sure that the hose pump or pump parts are not exposed to temperatures lower than -40 °C or higher than +60 °C.
- Cover the openings of the inlet and outlet ports.
- Prevent corrosion of untreated parts. For this purpose use the correct protection or packaging means.
- After a long period of standstill or storage, the static load on the pump hose may have caused permanent deformation, which will reduce the life of the pump hose. To prevent this, remove the pump hose.

8.2 Pump hose

- Store the pump hose in a cool and dark room. After two years the hose material will age, which will reduce the life of the hose.

9 TROUBLESHOOTING

**WARNING**

Disconnect and lock the power supply to the pump drive before any work is carried out.

In case the motor is fitted with a frequency controller and has a single-phase power supply, wait two minutes to make sure that the capacitors have discharged.

If the hose pump does not function (correctly), consult the following checklist to see if you can remedy the error yourself. If this is not the case, contact your Bredel representative.

Problem	Possible cause	Correction
Failure to operate.	No voltage.	Check that the supply power switch is on.
		Check the electrical supply is available at the pump.
	Stalled rotor.	Check if the pump is stalled by incorrect fitting of the hose.
	Lubricant level monitoring system has been activated.	Check that the lubricant level monitoring system has stalled the pump. Check the functioning of the lubricant level monitoring system, or check the lubricant level.

Problem	Possible cause	Correction
High pump temperature.	Non standard hose lubricant used.	Consult the Bredel representative for the correct lubricant.
	Low lubricant level.	Add Bredel Genuine Hose Lubricant. For the required amount of lubricant refer to § 10.1.5.
	Product temperature too high.	Consult the Bredel representative about the maximum temperature range of the product.
	Internal friction on the hose caused by blocked or poor suction characteristics.	Check pipework/valves for blockages. Ensure that the suction pipework is as short as possible and that the diameter is large enough.
	High pump speed.	Reduce pump speed to a minimum. Consult with your Bredel pump representative for advice on optimum pump speeds.

Problem	Possible cause	Correction
Low capacity / pressure.	Shut-off valve in the suction line (partly) closed.	Fully open the shut-off valve.
	Hose rupture or badly worn hose.	Replace hose. Refer to § 7.6.
	(Partial) blockage of the suction line or too little product on the suction side.	Ensure that the suction line is clear of blockages and that sufficient product is available.
	Connections and hose clamps not correctly mounted, which makes the pump suck air.	Tighten connections and hose clamps.
	The filling degree of the pump hose is too low, because the speed is too high in relation to the viscosity of the product to be pumped and the inlet pressure. The suction line can be too long or too narrow or a combination of these factors.	Consult your Bredel representative for a recommendation.

Problem	Possible cause	Correction
Vibration of the pump and pipework.	Suction and discharge lines are not secured correctly.	Check and secure pipe-work.
	High pump speed with long suction and discharge lines or high relative density or a combination of these factors.	Reduce pump speed. Reduce the line lengths on both suction and discharge where possible. Consult your Bredel representative for a recommendation.
	Too narrow diameter of suction and/or discharge line.	Increase the diameter of the suction/discharge lines.
Short hose life.	Chemical attack of the hose.	Check the compatibility of the hose material with the product to be pumped. Consult your Bredel representative for correct hose selection.
	High pump speed.	Reduce pump speed.
	High discharge pressures.	Maximum working pressure 750 kPa. Check that the discharge line is not blocked, the shut-off valves are fully opened and the pressure relief valve functions properly (if present in the discharge line).
	High product temperature.	Consult your Bredel representative for correct hose selection.
	High pulsations.	Restructure the discharge and inlet conditions.


Problem	Possible cause	Correction
Hose pulled into the pump.	Insufficient or no hose lubricant in the pump head.	Add extra lubricant. Refer to § 7.5.
	Incorrect lubricant: no Bredel Genuine Hose Lubricant in the pump head.	Consult the Bredel representative for the correct lubricant.
	Extremely high inlet pressure - larger than 200 kPa.	Reduce the inlet pressure.
Lubricant leakage at bracket.	Hose blocked by an incompressible object in the hose. The hose cannot be compressed and will be pulled into the pump housing.	Remove hose, check for blockages and replace if necessary.
	Bolts of bracket loose.	Tighten to the specified torque settings. Refer to § 10.1.7.
	Bolts of hose clamps loose.	Tighten to the specified torque settings. Refer to § 10.1.7.
Leakage from the rear of the pump housing "Buffer zone".	Damaged seal ring.	Replace seal ring.
Extreme corrosion inside the pump	When the pump temperature goes above 60 °C, the corrosion speed can rise excessively, depending on the product.	Lower the pump temperature, by using the pump intermittently. Or mount a temperature switch, to prevent the pump temperature from rising above 60 °C.

10 SPECIFICATIONS
10.1 Pump head
10.1.1 Performance

Description		DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
Max. capacity, continuous [m ³ /h]		0.11	0.38	0.62
Max. capacity, intermittent [m ³ /h] *		0.16	0.60	1.09
Capacity per revolution [l/rev]		0.022	0.083	0.152
Max. permissible working pressure [kPa]	with low-pressure rotor	400	400	400
	with medium-pressure rotor	750	750	750
Permissible ambient temperature [°C]		-20 to +45		
Permissible product temperature [°C]		-10 to +60		
Sound level at 1 m [dB(A)]		60		

* Intermittent duty: "Let the pump stand still to cool down for at least 1 hour after 2 hours of operation".

10.1.2 Materials



Pos	Description	Material
1	Pump housing	Cast-iron with DuCoNite® coating
2	Cover	Cast-iron with DuCoNite® coating
3	Pump rotor	Cast-iron with DuCoNite® coating
4	Pump support	AISI 316
5	Bracket	AISI 316
6	Fasteners	AISI 316
7	Seal	VITON
8	Seals, gaskets	EPDM
9	Fittings	PVC
10	Inspection cover	PVC
11	Coupling	Steel

10.1.3 Surface treatment

Pump head

The main pump head parts (pump housing, cover and rotor) are provided with a special **DuCoNite®** coating, which is both chemical and wear resistant. For the chemical resistance chart refer to § 10.1.4.

Gearbox-electric motor

After surface preparation, one layer of 2 component acrylate is used for surface protection. The standard colour is RAL 9005. Contact your Bredel representative for details on surface treatment.

10.1.4 Chemical resistance chart DuCoNite® coating

Chemical	Concentration	Chemical compatibility with DuCoNite®	Hose material
Sodium Hypochlorite	up to 18%	good	EPDM
Sodium Bisulphate	38%	good	EPDM
Ferric Chloride	up to 50%	good	EPDM
Ferrous Chloride	35%	good	EPDM
Alum	50%	good	EPDM
Polymer		good	EPDM
Fluoride (Hydrofluorosilicic Acid)	18-24%	limited	EPDM
Sodium Hydroxide	20-50%	good	EPDM
Potassium Permanganate	50%	good	EPDM
Potassium Hydroxide	up to 70%	good	EPDM
Aqueous Ammonia	20%	limited	EPDM
Methanol		good	EPDM
Sulfuric Acid	93-97%	good	CSM
Peroxide	50%	good	CSM
Citric Acid	50%	good	EPDM
Zinc Orthophosphate	25%	good	EPDM
Phosphoric Acid	50%	good	EPDM
Nitric Acid	25%	limited	CSM

If the ambient temperature is above 40 °C consult your Bredel representative.

10.1.5 Lubricant table pump

	DuCoNite® 10	DuCoNite® 15, DuCoNite® 20
Lubricant	Bredel Genuine Hose Lubricant	Bredel Genuine Hose Lubricant
Required quantity [litres]	0.5	1.0


Bredel Genuine Hose Lubricant is registered at NSF: NSF Registration N° 123204; Category Code H1. See also: www.NSF.org/USDA.

	Should you require additional information with respect to the safety data sheet, consult your Bredel representative.
---	--

10.1.6 Weights

Description	Weight [kg]	
	DuCoNite® 10	DuCoNite® 15, DuCoNite® 20
Main components:		
Pump head	12.0	22.0
Gearbox	9 - 11	9 - 11
Motor	4.5 - 9	4.5 - 9
Total unit:	26 - 32	36 - 42
Components:		
Hose	0.4	0.8
Lubricant	0.6	1.3
Gearbox GA52...	9.4	
Gearbox GA53...	11	
Motor 0.25 kW, E0...	4.5	
Motor 0.37 kW, E0...	6.5	
Motor 0.55 kW, E0...	9	

10.1.7 Torque figures



Pos	Description	Torques [Nm]	
		DuCoNite® 10	DuCoNite® 15, DuCoNite® 20
A	Cover	10	25
B	Hose clamp	3	3
C	Bracket	10	25
D	Support	10	10
E	Gearbox	10	10
F	Breather plug	3	3
G	Inspection window	1.5	1.5
H	Drain plug	3	3

10.2 Gearbox

Type	Co-axial gearbox with helical gears
Number of stages	Two or three
Lubrication	Lubricated for life
Mounting position	IM 2001 (IM B5) flanged gearbox with keyed shaft in horizontal position.
Motor adapter	Electric motor has been integrated in the gearbox housing, by which the smallest possible dimension is achieved.
Optional motor adapter	Adapters in conformance with IEC-B5 or NEMA TC.

10.3 Electric motor

Standard electric motor design is an enclosed three-phase asynchronous motor. A thermal safety device to prevent motor overload is optional.

	In case of doubt about the local applicable regulations for the drive connection, contact your Bredel representative.
---	---

Protection class	IP55/IK08
Insulation class	F
Increase in temperature	Within class B
Voltage/frequency	230/400 V - 3 phases - 50 Hz


10.4 Variable Frequency Drive (VFD) (optional)

The Bredel Variable Frequency Drive (VFD) has been preprogrammed and only needs to be connected to the mains.

RFI filter	Integrated RFI filter B (industrial applications).
Control	Manual control for setting the speed and the keys for starting forward, stop and starting reverse.
Protection class	IP65
Mains power supply	There are three types available; the choice depends on the local electricity grid: <ul style="list-style-type: none">• 200-240 V \pm 10%; 50/60 Hz \pm 5%; 1 ph• 200-240 V \pm 10%; 50/60 Hz \pm 5%; 3 ph• 400-480 V \pm 10%; 50/60 Hz \pm 5%; 3 ph


10.5 Parts list

10.5.1 Overview



Pos.	Description
1	Cover assembly. Refer to § 10.5.2.
2	Pump head assembly. Refer to § 10.5.3.
3	Pump support assembly. Refer to § 10.5.4.
4	Barbed nipple assembly. Refer to § 10.5.5.
5	Threaded nipple assembly. Refer to § 10.5.6.
6	Flange assembly (1). Refer to § 10.5.7.
7	Flange assembly (2). Refer to § 10.5.8.
8	Revolution counter assembly. Refer to § 10.5.9.
9	Lubricant. Refer to § 10.5.10.


10.5.2 Cover assembly



Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	1	Cover DuCoNite®	210102N	215102N	215102N
2	1	Gasket	29017349	29017349	29017349
3	1	Drain plug	29025348	29025348	29025348
4	2	Washer, M6	F523010	-	-
	4	Washer, M8	-	F523012	F523012
5	2	Bolt, hex. head, M6X20	F504038	-	-
	4	Bolt, hex. head, M8X25	-	F504055	F504055
6	1	Gasket	210156N	215156N	215156N
7	1	Inspection window	210155N	215155N	215155N
8	1	O-ring	-	S120113	S120113
9	1	Breather plug	-	29017463	29017463

Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
10	3	Round head screw, M6X16	F552536	-	-
	6		-	F552536	F552536
11	1	High level switch	900610	900610	900610
12	1	Breather housing	29086450	29086450	29086450
13	1	Gasket	29038352	29038352	29038352
14	1	Breather pipe	29060453	29060453	29060453
15	1	O-ring	S120263	S120263	S120263
16	1	Breather cap	29045221	29045221	29045221
17	1	Breather strip	29210222	29210222	29210222
18	2	O-ring	S120183	S120183	S120183
19	1	Breather connection plug	29034451	29034451	29034451
20	1	DuCoNite® sticker	210239	215239	220239
21	1	Drain pipe	29060454	29060454	29060454


10.5.3 Pump head assembly



Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	1	Hose NR	010020	015020	020020
	1	Hose NBR	010040	015040	020040
	1	Hose EPDM	010075	015075	020075
	1	Hose CSM	010070	015070	020070
2	1	Rotor DuCoNite® , low pressure	210103LN	215103LN	220103LN
		Rotor DuCoNite® , medium pressure	210103HN	215103HN	220103HN
3	1	Circlip, A50	F343043	F343043	F343043
4	2	Bearing	B141060	B141060	B141060
5	1	Retaining ring	29080297	29080297	29080297
6	1	Spacer ring	29070201	29070201	29070201
7	1	Seal ring	S311815	S311815	S311815
8	1	Gasket	210123	215123	215123
9	1	Pump housing DuCoNite®	210101N	215101N	215101N


Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
10	4	Stud, M6X20	F511001	F511001	F511001
11	1	Coupling, Ø 20 x 63 mm	29063255	29063255	29063255
		Coupling, Ø 20 x 68 mm	29068255	29068255	29068255
		Coupling, Ø 25 x 63 mm	29064255	29064255	29064255
		Coupling, Ø 25 x 68 mm	29069255	29069255	29069255
12	1	Plug	29033347	29033347	29033347
13	1	O-ring	S120163	S120163	S120163
14	1	Nut	29025346	29025346	29025346

10.5.4 Support assembly




Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	1	Pump support	210106A	215106A	215106A
2	4	Washer, M6	F532008	F532008	F532008
3	4	Nut, hex. head, M6	F516010	F516010	F516010

10.5.5 Barbed nipple assembly (PTFE/PDVF)




Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	2	Rubber bush	210119	215119	215119
2	2	Hose clamp	C112507	C112508	C112508
3	2	Barbed nipple PTFE	210688010	215688015	215688020
		Barbed nipple PVDF	210690010	215690015	215690020
4	2	Bracket	210197	215197	215197
5	4	Washer, M6	F532008	-	-
		Washer, M8	-	F532009	F532009
6	4	Bolt, hex. head, M6X16	F504036	-	-
		Bolt, hex. head, M8X20	-	F504054	F504054

10.5.6 Barbed or threaded nipple assembly (stainless steel)




Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	2	Rubber bush	210119	215119	215119
2	2	Hose clamp	C112507	C112508	C112508
3	2	Threaded nipple (BSP) SS	210693010	215693015	215693020
		Barbed nipple SS	210686010	215686015	215686020
		Threaded nipple DIN 11851 SS	210702010	215702015	215702020
		Threaded nipple (NPT) SS	210698010	215698015	215698020
		Threaded nipple (NPT) PP	210696010	215696015	215696020
		Threaded nipple (NPT) PVC	210697010	215697015	215697020
4	2	Bracket	210197	215197	215197
5	4	Washer, M6	F532008	-	-
		Washer, M8	-	F532009	F532009
6	4	Bolt, hex. head, M6X16	F504036	-	-
		Bolt, hex. head, M8X20	-	F504054	F504054

10.5.7 Flange assembly (1)




Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	2	Rubber bush	210119	215119	215119
2	2	Hose clamp	C112507	C112508	C112508
3	2	Flange bracket	210197A	215197A	215197A
4	2	Flange DIN SS	210199	215199	215199
		Flange ANSI SS	210199A	215199A	215199A
		Flange DIN/ ANSI Titanium	210195	215195	215195
5	2	Insert PP	210189	215189	220189
		Insert SS	210186	215186	220186
		Insert Titanium	210186A	215186A	220186A
6	4	Washer, M6	F532008	-	-
		Washer, M8	-	F532009	F532009
7	4	Bolt, hex. head, M6X16	F504036	-	-
		Bolt, hex. head, M8X20	-	F504054	F504054

10.5.8 Flange assembly (2)



Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	2	Rubber bush	210119	215119	215119
2	2	Hose clamp	C112507	C112508	C112508
3	2	Threaded nipple (BSP) SS	210693010	215693015	215693020
4	2	Nut, G1/2	F519003	-	-
		Nut, G3/4	-	F519004	F519004
5	2	Flange DIN SS	A304504	A304505	A304505
		Flange ASA SS	A305504	A305505	A305505
6	2	Bracket	210197	215197	215197
7	4	Washer, M6	F532008	-	-
		Washer, M8	-	F532009	F532009
8	4	Bolt, hex. head, M6X16	F504036	-	-
		Bolt, hex. head, M8X20	-	F504054	F504054

10.5.9 Revolution counter assembly



Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	1	Plug	29033459	29033459	29033459
2	1	O-ring	S120163	S120163	S120163
3	1	Nut	29025368	29025368	29025368
4	1	Revolution counter	29050368	29050368	29050368

10.5.10 Lubricants

Pos.	Qty.	Description	DuCoNite® 10	DuCoNite® 15	DuCoNite® 20
1	1	0.5 l can Bredel Genuine Hose Lubricant	901143	-	-
	2		-	901143	901143

EC DECLARATION OF CONFORMITY FOR MACHINERY

(according to Annex II.1.A. of Directive 2006/42/EC on machinery)

We,
Watson-Marlow Bredel B.V.
Sluisstraat 7
P.O. Box 47
7490 AA Delden
The Netherlands,

herewith declare, on our own responsibility, that the following machinery fulfils all the relevant provisions of Directive 2006/42/EC:

Peristaltic hose pump: **DuCoNite® 10-20** series,

for the transportation of various kinds of fluids.

In addition, the machinery complies with the harmonised standard(s), other standards or technical specifications, applicable requirements of these standards and/or specifications as listed below:

NEN-EN 809
NEN-EN-ISO 12100-2
NEN-EN-IEC 60204-1

The undersigned is responsible for compilation of the technical file and makes this declaration on behalf of the manufacturer.

J. van den Heuvel
Managing Director

The Netherlands, Delden
1 June 2013

SAFETY FORM

Product Use and Decontamination Declaration

In compliance with the **Health and Safety Regulations**, the user is required to declare those substances that have been in contact with the item(s) you are returning to Watson-Marlow Bredel B.V. or any of its subsidiaries or distributors. Failure to do so will cause delays in servicing the item or in issuing a response. Therefore, **please complete this form** to make sure we have the information before receipt of the item(s) being returned. A completed copy must be attached to **the outside of the packaging** containing the item(s). You, the user, are responsible for cleaning and decontaminating the item(s) before returning them.

Please complete a separate Decontamination Certificate for each item returned. **RGA/KBR no**.....

1 Company

Address

Postal code.....

Telephone Fax number

2 Product 3.4 Cleaning fluid to be used if residue of chemical is found during servicing;

2.1 Serial Number

2.2 Has the Product been used? a)

YES NO b)

If yes, please complete all the following paragraphs. c)

If no, please complete paragraph 5 only d)

3 Details of substances pumped 4 I hereby confirm that the only substances(s) that the equipment specified has pumped or come into contact with are those named, that the information given is correct, and the carrier has been informed if the consignment is of a hazardous nature.

3.1 Chemical Names

a)

b)

c)

d)

3.2 Precautions to be taken in handling these substances: 5 Signed

a)

b)

c)

d)

Name

Position

Date

3.3 Action to be taken in the event of human contact: **Note:**

a)

b)

c)

d)

To assist us in our servicing please describe any fault condition you have witnessed.

.....

.....

.....

Watson-Marlow Bredel B.V.
P.O. Box 47
NL-7490 AA Delden
The Netherlands
Telephone: +31 (0)74 3770000
Fax: +31 (0)74 3761175

E-mail: bredel@wmpg.com
Internet: <http://www.bredel.com>



© 2013 Watson-Marlow Bredel B.V.