

APEX NR Hose 10

APEX NR hose

Bredel

Hose Pumps

Features and benefits

- Tight tolerances for low stress on bearings
- Perfect compression for long life
- Excellent suction capability up to 9.5 mWC (374 inWC)
- High pressure capability 8 bar (115 psi)
- Repeatable volumetric accuracy to
- Consistent capacity independent of varying suction and discharge conditions
- Exceptional performance when handling high viscosity product
- Max. fluid temperature: 80 °C (176 °F), Min. fluid temperature: -20 °C (-4 °F)



Technical specifications

	APEX NR Hose 10
Max. operating pressure	8 bar (115 psi)
Max. suction capability	9.5 mWC (374 inWC)
Suction capability (80% Flow rate)	9.5 mWC (374 inWC)
Operating temperature	-20 °C to 45 °C (-4 °F to 113 °F)
Fluid temperature	-20 °C to 80 °C (-4 °F to 176 °F)
Bore size	10 mm (0.39 in)
Wall thickness	8.5 mm (0.335 in)
Length	700 mm (27.5 in)
Weight	0.4 kg (0.88 lbs)

Your local Bredel sales office/distributor can advise the right hose for your application. For best pump performance use Bredel Genuine Hose Lubricant (NSF Non food Compound Program Listed, category H1)

Materials of construction

	APEX NR Hose 10
Material	Natural rubber (NR)
Inner layer	Natural rubber (NR)
Outer layer	Natural rubber (NR)

Hose composition



1. Rough hose surface prior to machining.
2. Precision machined NR outer layer.
3. Two or four nylon cord reinforcement layers.
4. Inner layer available in NR, EPDM, NBR, F-NBR or CSM.

Product codes

A: Pump type High precision pump element machined for

B: Re-order number **APEX 15**

C: Bore size 300002020

D: Material of the inner layer 15 mm NR

E: Maximum permitted pressure 8 bar 115 psi

F: Factory code N7A

[material;year;month]

E=F-NBR / M=CSM / N=NR / P=NBR / S=EPDM

Bredel
Hose Pumps

Year : last digit (7 = 2017) Month : A = Jan, E = May
(Code is engraved on the end of each hose)

Disclaimer: The information contained in this document is believed to be correct at the time of publication, but Watson-Marlow Bredel BV accepts no liability for any error it contains, and reserves the right to alter specifications without prior notice. All mentioned values in this document are values under controlled circumstances at our test bed. Actual flow rates achieved may vary because of changes in temperature, viscosity, inlet and discharge pressures and/or system configuration. APEX, DuCoNite, Bioprene and Bredel are registered trademarks.



wmfts.com/global
28 October 2025